



**USER MANUAL**  
**GLASS WARMING TRAY**

**SYMBOLS USED IN THIS MANUAL**

Read the instructions before using the appliance



Important safety instructions. Imminent danger of accident if not observed.



***Practical note for the user.***



Instructions for qualified persons only.

**1. Safety and proper use****1.1. Safety instructions**

The equipment is safe to use and meets the current European safety requirements. However, improper use can lead to personal injury and property damage. To ensure correct and safe operation, read this manual before using the equipment. This manual contains important warnings about installation, safety, use and care of the equipment.

Keep this manual for future reference. Give the manual together with the equipment to a possible new owner of the equipment.

The manufacturer cannot be held responsible for damages that result from inappropriate or incorrect use. Please note that the instructions in this manual do not replace the technical characteristics engraved on the rating plate fixed to the equipment.



**Read the safety instructions carefully!**



During installation: do not place on surfaces or close to walls, partitions, kitchen furniture or similar - unless they are made of non-combustible material or covered with thermally insulating and non-combustible material, and attention is paid to fire prevention regulations..



**Before using the equipment, check that no damage is visible. Never use a damaged device.**



**To avoid risk of damage to the equipment, check that the data indicated on the rating plate of the equipment corresponds to the voltage and frequency of the power supply.**



**Connect the equipment to an earthed electrical circuit. The electrical safety of the equipment is only guaranteed if it has a correct connection.**



**Do not connect the equipment to the power supply using a multiple plug or an extension lead. These do not guarantee the safety of the device.**



**Only qualified and authorised persons may carry out installation and repairs to the equipment. The manufacturer is not responsible for damage resulting from repairs or other interventions carried out by unqualified persons.**



**Installation and repair interventions must strictly comply with the local and national safety regulations in force.**



**Keep the equipment clean at all times by carrying out a thorough cleaning on a regular basis! Food residues increase the risk of fire!**



**Danger of burns! Do not touch work surfaces and metal parts while the equipment is running.**

## 1.2. Purpose of use

The plate warmer serves to heat plates. The manufacturer does not recommend any other use, as this could be dangerous.

The plate warmer is intended for commercial use. Do not use the appliance outdoors.

## 1.3. User requirements

The equipment should be kept out of the reach of children and they should be supervised to ensure that they do not play with the equipment.

## 1.4. Recycling

Treatment of packaging material: Before using the device for the first time, remove the protective plastics from the stainless steel. Recycle the transport packaging and all protective materials.



**Ensure safe disposal of all plastic packaging. Keep plastic packaging out of the reach of children. Danger of suffocation!**



Electrical and electronic equipment contains materials that when incorrectly handled can endanger human health and the environment. Do not dispose of any part or component of the equipment in domestic waste, take them to collection/recycling facilities or contact your supplier or local authority for advice.

## 2. Description

- Keeps meals hot and reduces time before serving;
- General construction in stainless steel AISI 304;
- Tempered glass plate of 6mm;
- Temperature regulated and controlled through an analogue thermostat from 0°C to 90°C and a light switch;
- Resistances in silicone;
- Safety thermostat;
- Connecting cable 1.5m with plug;
- Voltage 230V/50Hz.

### 2.1. Technical features

Model	Dim. plate (usable area) WxDxH(mm)	Power (W)	Voltage (V/Hz)
PLACA AQUEC. DE PRATOS 800W	500X500X100	800	230V/50Hz
PLACA AQUEC. DE PRATOS 800W	650X550X100		
PLACA AQUEC. DE PRATOS 1600W	1000X550X100	1600	230V/50Hz

### 2.2. Required links

Electrical connection with protective earthing

### 2.3. Location of use

Choose a dry place where the equipment cannot come into direct contact with water.

Never direct jets of water at the equipment.



Place the equipment on a stable, level surface.

Keep the equipment away from flammable materials or deformable by heat. If this is not possible, insulate the space around the equipment with a non-flammable, heat-resistant insulating material.

#### 2.4. Unpack

Remove all protective material from the packaging. Check the equipment .

Remove the protective plastics from the stainless steel. Clean the outside of the appliance with a damp cloth.

Dispose of protective and packaging material safely as potential sources of danger.


#### 2.5. Electrical installation

Check that the data indicated on the rating plate of the unit corresponds to the voltage and frequency of the power supply.

Connect the equipment to an earthed electrical circuit!

Connect the equipment to a fixed installation. Never connect the equipment to multiple sockets, T-type adapters or extension leads.

Follow the regulations in force in the country you are in.

On the back of the appliance there is a terminal marked with the symbol  for equipotential bonding between different appliances.

### 3. Operating instructions

- Before using the appliance you must remove all the protective plastic from the casing and clean the glue particles with non-abrasive products so as not to damage the appliance.
- After removing all the plastic, clean the slab with a suitable detergent, then grease the slab.
- When choosing where to place the appliance, make sure that it is level and that its surface is made of non-combustible material. The appliance should also be kept away from walls and other materials which may break up or catch fire when heated.
- When choosing where to place the appliance, make sure that it is level and that its surface is made of non-combustible material. The appliance should also be kept away from walls and other materials which may break up or catch fire when heated.
- After the previous checks, you can use the appliance by connecting the power cable to the mains and turning the temperature knob to the desired value. Let the plate heat up and then start using it .
- Never operate the appliance with wet hands!

- When using the appliance, do not place cloths or other objects on it which might damage it or create a dangerous situation.
- Please note that the power cable must not come into contact with hot parts .
- ⚠ **The handling of cooking utensils should not cause any damage to the covering (cracks or lifting).**
- ⚠ **Do not use any abrasive material (solid or liquid) or sharp or pointed objects when handling or cleaning the hob.**
- Empty the grease trimmer periodically so that it does not overflow onto the front panel. To do this, care must be taken to allow the trimmer to cool down, so as to avoid burns from direct contact or spillage of the contents onto the operator.

#### 4. Cleaning

- When cleaning the appliance, make sure the power cable is disconnected from the mains and that the appliance is completely cool.
- Clean the outside of the fry top with a damp cloth and some washing up liquid.
- To clean the hob more easily, place a little water on the hob and turn the appliance on to the minimum temperature until the water bubbles and facilitates the release of trapped particles.
- After cooling down using a damp cloth and, if necessary, mild detergent, finish cleaning.
- Remove the grease trimmer when it is cold and clean it (if necessary, immerse in hot water for more effective cleaning).
- **Carry out this operation at the end of each use, but never when the hob is hot!**
- **The parts, especially in the working area, must never be cleaned using detergents or utensils that cause abrasion, wear or corrosion.**
- ⚠ • **When cleaning the appliance, do not use water jets as there is a risk of damaging the electrical part.**

#### 5. Maintenance

Only qualified and authorised persons may carry out installation and repairs to the equipment. The manufacturer is not responsible for damage resulting from repairs and other interventions carried out by unqualified persons.


Installation and repair interventions must strictly comply with the local and national safety regulations in force.

##### 5.1. Replacing the power cable

Should the power cable be damaged, it must be replaced with a special cable supplied by the manufacturer or its official representative:

⚠ 5.2 Indication of use for greater durability of the coating:

- ⚠ No abrasive material (solid or liquid) should be used.

 Do not use pointed or sharp-edged objects .

Storage must avoid friction between coated parts or with other aggressive materials.

#### 6. Warranty

- ❑ The equipment is guaranteed for a period of 12 months from the date of purchase .
- ❑ The guarantee is valid against original defects, whether material or manufacturing .
- ❑ Whenever there is an anomaly in the equipment, it should be returned as soon as possible, enclosing the purchase document.
- ❑ When the guarantee is triggered, the damaged parts will be repaired or replaced at the manufacturer's discretion. In the event of replacement, the damaged parts will become the property of the supplier.
- ❑ Any and all faults resulting from poor installation or use/handling of the equipment are excluded from the scope of the warranty.
- ❑ The equipment will lose its guarantee whenever any alteration/modification or even repair carried out by the user is identified.

RUA DO ALTO

VALE DO GROU – APARTADO 86

3750 - 064 AGUADA DE CIMA

TEL. +351 234 690 190

geral@pnh-bypinha.pt

**P N H**

PROFESSIONAL  
FURNITURE  
& INNOVATION



**P N H**

PROFESSIONAL  
FURNITURE  
& INNOVATION